



US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448

US SPARS is a part of group Z-Spars, the world's largest spar builders. From a small shop in Paris making bows and arrows to the largest spar-producing group on the planet, the Z-Spars Group is now at the forefront of the spar design. The Z-Spars Group has been supplying custom and production spars and rigging since 1973 and now supplies sailing enthusiasts and boat builders of the world with over 6,000 spars annually. With a network of smaller agents, we can supply products to every country in the world.


Established in 1998, US SPARS extends the Z-Spars line of boating products to better serve our US customers. US SPARS staff take pride in the exceptional customer service and individual attention given to all of our customers.



US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448






US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448






US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448



Screw 8x20mm
#1701

Counter-Sync Screw
8x20mm #87

Sheave Box #3028

- Sheave Box #1060
- Sheave #1707
- Sheave Pin #5816
- Rivet #5391

Forestay Tang #5241

Screw 6x16mm #5819

Fender Washer 6mm #5858

Forestay Tang Pin #5827

Forestay Attachment #1344

Sheave Box #3036


- Sheave Box #1058
- Mark Pin #1273
- Sheave #1618
- Rivet #1369



US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
 6320 NW 123rd Place
 Gainesville, FL 32653
www.usspars.com
 Tel : 386-462-3760
 Fax : 386-462-3448



Spreader Plate
#4912

Spreader Bar
#5044

Screw 6x8mm #101




Upper Spreader Tip #3115

- Spreader Tip #1670
- Spreader End Hook #4235
- Screw 6x60mm #5900
- Pack Washer 6mm #5894
- Screw 6x50mm #86
- Washer 6mm #1752
- Nut 6mm #88

Sheave Box #3036

- Sheave Box #1058
- Mark Pin #1273
- Sheave #1618
- Rivet #1369



Fairlead #4976



Spreader Plate
#4912

Spreader Bar
#5044

Screw 6x8mm
#101



Lower Spreader Tip #3111

- Spreader Tip #1155
- Pin 16x80mm #1325
- Pin 12x80mm #1326
- Split Pin #1776
- Screw 8x55mm #5925
- Washer 8mm #1718
- Nyloc Nut 8mm #1710




US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448

Port Side Halyard Exits

Starboard Side Halyard Exits





US SPARS


Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448



Halyard Swivel #3164

- Shackle #3168
- Swivel Casting #15
- Bearing Module #3893
- Wedge Spacer #23
- Bushing #4617
- Screw 8x25mm #133
- Screw Cover #1566
- Circlips #26
- Inner Casting #13



Screw 6x6mm #5951

Access Plates #4397

Screw 6x6mm #5951


Access Plates #4397



US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
 6320 NW 123rd Place
 Gainesville, FL 32653
www.usspars.com
 Tel : 386-462-3760
 Fax : 386-462-3448





US SPARS

Jeanneau 41 RF Parts Manual

U.S. SPARS
6320 NW 123rd Place
Gainesville, FL 32653
www.usspars.com
Tel : 386-462-3760
Fax : 386-462-3448



Base Block Plate #4720E

- Base Block Plate #4720
- Screw 10x25mm #6017
- Washer 10mm #5330
- 10mm Nylon Washer #4522
- Nut 10mm #1648

Mast Base #4873

Stud Pin #4810



Stud Pin #4810
With Nut #1648